

Recordex SimplicityTouch Panel Cleaning Instructions

Cleaning Fingerprints and Smudges

1. Turn the panel **off**.
2. Gently wipe the screen with the **microfiber cleaning cloth** provided with the SimplicityTouch panel.

Note: If the original cloth is not available, use a similar eye glass or computer screen microfiber cloth or a soft lint-free cloth that does not leave residue behind.

Using Screen Cleaning Wipes

*If a panel needs to be cleaned with more than a dry microfiber cloth, you must use a **certified electronic screen cleaning wipe**. **NEVER spray any liquid** directly on to the SimplicityTouch panel.*

1. Turn the panel **off**.
2. Squeeze excess moisture from the electronic screen cleaning wipe.
3. Gently wipe the screen.
4. Use a microfiber cleaning cloth to wipe any residue from the panel.

Note: Do not turn on the panel until the screen is completely dry.

Suggested Electronic Screen Cleaning Wipes

- Windex Electronics Wipes
- iCloth Large Screen Cleaning Wipes
- Care Touch Lens Cleaning Cloths
- Endust for Electronic Screens, Surface Cleaning Wipes